

Attaching the stand:

The stand is attached approximately 30 cm higher than the animal's height of the withers, measured from the joint on the stand. For cows, the usual height of the joint is about 1.8 m.

